





LONDON COLLECTION



SECTIONAL

- Pictured in White with Canvas Fern cushions.
- Shown with (1) LE Sectional Lounge, (1) Sectional Corner, and (1) RE Sectional Sofa.
- Comes standard with seat & back cushions. Pillows are optional.

This sectional is built for simple installation. Simply latch the ends together using the attached L-brace, then tighten a single hand bolt in the back to secure the two pieces together.



SECTIONAL CORNER | LOSCOR

- Size: 40 D x 40 L x 41 H
- Seat Size: 28 x 28



SECTIONAL CHAIR | LOSC

LE/RE CHAIR*

- Size: 34 D x 28 L x 41 H
- Seat Size: 22 x 24

EX CHAIR

- Size: 34 D x 24 L x 41 H
- Seat Size: 22 x 48



SECTIONAL LOUNGE | LOSL

LE/RE LOUNGE*

- Size: 34 D x 52 L x 41 H
- Seat Size: 22 x 48

EX LOUNGE

- Size: 34 D x 48 L x 41 H
- Seat Size: 22 x 48



SECTIONAL SOFA | LOSS

LE/RE SOFA*

- Size: 34 D x 76 L x 41 H
- Seat Size: 22 x 72

EX SOFA

- Size: 34 D x 72 L x 41 H
- Seat Size: 22 x 72



Arm Rest Location: LE = Left End | RE = Right End | EX = Extension (no arm rest) *LE Shown



Your space, your way! Completely modular sectional with superior flexibility.



MODULAR SECTIONAL

- Pictured in Coastal Gray with Cove Pebble cushions.
- Shown with (1) LE Rocking Chair, (1) Extension Rocking Chair, (1) Corner Table, (1) Extension Chair, (1) Console, and (1) RE Chair.
- Comes standard with seat & back cushions.

This sectional is built for simple installation. Sections simply nest together using the attached L-brace, giving you the opportunity to reconfigure everything to fit your space best.





SECTIONAL PIECES



SECTIONAL CORNER | BRSCOR

- Size: 41 W x 41 D
- Seat Size: 28 W x 28 D



SECTIONAL CORNER TABLE | BRSCORT

- Size: 36 W x 36 D
- No seating available on this piece.



SECTIONAL LE/RE END CHAIR | BRSEC

- LE Chair Shown
- Size: 28 W x 34 D
- Seat Size: 24 W x 21½ D



SECTIONAL EXTENSION CHAIR | BRXSC

- Size: 24 W x 34 D
- Seat Size: 24 W x 21½ D



SECTIONAL LE/RE END ROCKING CHAIR | BRSERC

- LE Chair Shown
- Size: 25 W x 34 D
- Seat Size: 24 W x 21½ D



SECTIONAL EXTENSION ROCKING CHAIR | BRXSRC

- Size: 25 W x 34 D
- Seat Size: 24 W x 21½ D



SECTIONAL CONSOLE | BRSCL

- Size: 13 W x 34 D
- Seat Size: 12 W x 21½ D



Arm Rest Location: LE = Left End | RE = Right End






HERITAGE COLLECTION




SECTIONAL

- Pictured in Black with Harwood Crimson cushions.
- Shown with (1) LE Sectional Lounge, (1) Sectional Corner, and (1) RE Sectional Sofa.
- Comes standard with seat & back cushions. Pillows are optional.



This sectional is built for simple installation. Simply latch the ends together using the attached L-brace, then tighten a single hand bolt in the back to secure the two pieces together.



SECTIONAL CORNER | HCSCOR

- Size: 40 D x 40 L x 35 H
- Seat Size: 28 x 28



SECTIONAL CHAIR | HCSC

- | | |
|----------------------------|----------------------------|
| LE/RE CHAIR* | EX CHAIR |
| • Size: 34 D x 28 L x 35 H | • Size: 34 D x 24 L x 35 H |
| • Seat Size: 22 x 24 | • Seat Size: 22 x 48 |



SECTIONAL LOUNGE | HCSSL

- | | |
|----------------------------|----------------------------|
| LE/RE LOUNGE* | EX LOUNGE |
| • Size: 34 D x 52 L x 35 H | • Size: 34 D x 48 L x 35 H |
| • Seat Size: 22 x 48 | • Seat Size: 22 x 48 |



SECTIONAL SOFA | HCSSL

- | | |
|----------------------------|----------------------------|
| LE/RE SOFA* | EX SOFA |
| • Size: 34 D x 76 L x 35 H | • Size: 34 D x 72 L x 35 H |
| • Seat Size: 22 x 72 | • Seat Size: 22 x 72 |



Arm Rest Location: LE = Left End | RE = Right End | EX = Extension (no arm rest) *LE Shown

